```
`timescale 1ns / 1ps
*********
\star
* Module: Mod Counter
\star
 Author: Eric Christie
* Class: ECEN 220, Section 1, Winter 2021
* Date: 3/9/21
\star
* Description: Basic Modulus Counter for
stopwatch project. Counts up to max value
                   then rolls to 0
based on the input signals and clock.
*
*********
**********
`default nettype none
module Mod Counter #(parameter
MOD VALUE=10, WID = 4)(
   input wire logic clk, reset, increment,
   output logic rolling over,
```

```
output logic [WID-1:0] count);
    always_ff @(posedge clk) begin
        if (reset)
            count <= 0;
        else if ((count == (MOD VALUE - 1))
&& increment)
            count <= 0;
        else if(increment)
            count <= count + 1;</pre>
    end
    assign rolling over = ((count ==
(MOD VALUE - 1)) && increment); //1 when
endmodule
```