```
`timescale 1ns / 1ps
/***********
*********
\star
* Module: Stopwatch
\star
* Author: Eric Christie
* Class: ECEN 220, Section 1, Winter 2021
* Date: 3/9/21
\star
* Description: Instances the Mod Counter
module to create a 4-digit stopwatch based
on a 100 Hz counter
**********
************
`default nettype none
module Stopwatch(
   input wire logic clk, reset, run,
   output logic [3:0] digit0, digit1,
```

```
logic timer runover;
   logic [19:0] timer out;
   logic [3:0] runover;
   //module Mod Value, WID clk,
reset, increment, rolling over, count (WID)
   Mod Counter #(1000000, 20) Timer(clk,
reset, run, timer runover, timer out);
   Mod Counter #(10, 4) D0(clk, reset,
timer runover, runover[0], digit0);
   Mod Counter #(10, 4) D1(clk, reset,
runover[0], runover[1], digit1);
   Mod Counter #(10, 4) D2(clk, reset,
runover[1], runover[2], digit2);
   Mod Counter #(6, 4) D3(clk, reset,
runover[2], runover[3], digit3);
```

endmodule

digit2, digit3);